

CLEANING GUIDE

SELF CLEANING MODE

1. Remove as much food as possible before using the self clean mode.
2. Add 1 liter of water and 1 drop of soap to the mixing bowl, then attach and lock the lid and measuring cup into place.
3. Flip the power switch to on, press program button, then select program P05.
4. Press the start button. The machine will begin to heat up to 55C (131F) and then the blender will spin for 3:00 minutes at high speed.

MANUAL CLEANING

WARNING: THE BOWL IS NOT DISH WASHER SAFE

1. Using the included brush, you can rinse and scrub off any food build up remains after use.
2. Alternatively, you can use a Brillo Pad or any other type of sturdy scrub to remove left over residue.
3. Scrub and rinse carefully with hot water and soap in order to remove build up effectively.

ATTENTION

Do not let the pins on the underside of the mixing bowl get wet. If the connection pins are exposed to water it is critical that you dry them immediately. This will prevent water from leaking into the machine through the connection pins, which can cause corrosion.

WATER DAMAGE IS NOT COVERED BY THE WARRANTY

