MODEL: Paris ASSEMBLY INSTRUCTION ASSEMBLY TIPS: Remove hardware from box and sort by size. Check that all hardware and parts are present before assembling. Following instruction below in proper sequence to ensure fast, easy and correct assembly. WARNING: DO NOT FULLY TIGHTEN ALL BOLTS UNTIL ALL PARTS IN PLACE. FAILURE TO FOLLOW THIS INSTRUCTION MAY CAUSE THE BOLTS TO BE MISALIGNED DURING THE ASSEMBLY. Step 01 Part List x 1 ard & Footboard В x 2 (C) Side Rail x 4 x 4 x 4 Step 02 Step 03 Support Leg F x 1 Center Rail G x13 Hardware List (h)x16 а JCBC M6 x 50 mm b JCBC M6 x 60 mm x 20 C Flat Washer M6 d x 8 Support leg should have approx 1cm of space from the floor when installed . JCBB M8 x 50 mm Please note, if support legs are in contact with the floor when the bed is not in use, Step 04 they can prevent the slats from functioning as intended as well as risk damage to the x 8 е JCBB M8 x 20 mm f x 8 Flat Washer M8 g x 26 CSK M4 x 25 mm x 4 h Adjuster Screw x 2 JCBC M6 x 30 mm x 1

COMPLETED ASSEMBLY

x 1

Allen Key M5

k