MODEL: Paris ASSEMBLY INSTRUCTION ASSEMBLY TIPS: Remove hardware from box and sort by size. Check that all hardware and parts are present before assembling. Following instruction below in proper sequence to ensure fast, easy and correct assembly. WARNING: DO NOT FULLY TIGHTEN ALL BOLTS UNTIL ALL PARTS IN PLACE. FAILURE TO FOLLOW THIS INSTRUCTION MAY CAUSE THE BOLTS TO BE MISALIGNED DURING THE ASSEMBLY. Step 01 Part List 5 x 1 leadboard & Footboard В x 2 Side Rai D x 4 x 4 Step 02 Step 03 Metal Center rail Ε x 2 x 13 Slat Hardware List 1 x 16 JCBC M6 x 50 mm 2 x 16 Flat Washer M6 x 8 3 Step 04 JCBB M8 x 50 mm **COMPLETED** x 8 4 **ASSEMBLY** Flat Washer M8 5 x 8 JCBB M8 x 20 mm 6 x 26 CSK M4 x 25 mm x 8 JCBC M6 x 16 mm 8 x 1 9 x 1 Allen Key M5