

**SMAI**

# **BO STAFF RACK FREESTANDING ASSEMBLY GUIDE**



## STEP 1

Assemble the Uprights by sliding 3 x curved base supports into the bottom of the uprights





## STEP 2

Assemble the base, before inserting the 2 x up-rights into the slots on the base. The base is 4 pieces, including 2 x Feet and 2 x cross beams.





## STEP 3

Install the upper and middle horizontal cross beams to complete the assembly.

