



 POWER	<b>Turning On/Off</b>	<p><b>To Turn On:</b></p> <ol style="list-style-type: none"><li>1. Plug in the dehumidifier. It will beep once.</li><li>2. Press the power button. The dehumidifier will beep once, and the power indicator light will turn on.</li></ol> <p><b>To Turn Off:</b></p> <ol style="list-style-type: none"><li>1. Press the power button again. The power indicator light will turn off.</li></ol> <p><b>Note:</b> When the indoor humidity reaches the target value, the compressor will stop running, and the indicator light will flash.</p>
 MODE	<b>Selecting a Mode</b>	<ol style="list-style-type: none"><li>1. Plug in and turn on the dehumidifier.</li><li>2. Press the humidity setting button repeatedly to cycle through the modes:</li></ol> <p><b>Continuous Dehumidification Mode:</b></p> <ul style="list-style-type: none"><li>• Default mode when plugged in.</li><li>• Laundry Drying Tip: Press the fan speed button to set the fan to high for efficient drying. Place the dehumidifier near the laundry in a well-ventilated room.</li></ul> <p><b>Relative Humidity Mode:</b></p> <ul style="list-style-type: none"><li>• Press the humidity setting button to cycle from 30% and 90% in 5% increments.</li><li>• Compressor turns off if ambient humidity is 3% below the set target and restarts if it's 3% above the target.</li></ul> <p><b>Automatic Dehumidification Mode:</b></p> <ul style="list-style-type: none"><li>• Below 5°C: Compressor off.</li><li>• 5°C - 20°C: Target humidity set to 60%.</li><li>• 20°C - 27°C: Target humidity set to 55%.</li><li>• Above 27°C: Target humidity set to 50%.</li></ul>
 FAN	<b>Setting the Fan Speed</b>	<p><b>Adjust Fan Speed:</b></p> <ol style="list-style-type: none"><li>1. While the dehumidifier is on, press the fan speed button repeatedly to cycle through low and high fan speed options.</li><li>2. The corresponding indicator light (high or low fan speed) will turn on.</li></ol>
 TIMER	<b>Setting a Turn-On Timer</b>	<ol style="list-style-type: none"><li>1. Plug in the dehumidifier.</li><li>2. Press the timer button repeatedly to cycle through 1 to 24-hour options.</li><li>3. When the display stops flashing, the timer is set. The timer indicator light will be on.</li><li>4. The dehumidifier will turn on when the set time elapses.</li><li>5. To cancel, press the power button at any point.</li></ol>

	<b>Setting a Turn-Off Timer</b>	<ol style="list-style-type: none"><li>1. Plug in and turn on the dehumidifier.</li><li>2. Press the timer button repeatedly to cycle through 1 to 24-hour options.</li><li>3. When the display stops flashing, the timer is set. The timer indicator light will be on.</li><li>4. The dehumidifier will turn off when the set time elapses.</li><li>5. To cancel, press the power button at any point.</li></ol>
--	---------------------------------	--

**EMPTYING THE WATER TANK**

When the water tank is full the indicator light will turn on, and the compressor will turn off.



1. Unplug the dehumidifier and place it on a flat, stable surface.
2. Grip each side of the water tank and gently pull it out. Do not pull from the continuous drainage port hole.
3. Empty the water tank and slot it back into the appliance.
4. Press the power button to turn the appliance back on.

**Note:** The water tank indicator light will turn on if the tank is missing or incorrectly placed.

**SETTING UP CONTINUOUS DRAINAGE**

For long term use it is recommended to connect a hose for continuous drainage.

1. Remove the water tank.
2. Attach one end of the continuous drainage hose to the drainage port and place the other end downwards to where you want the water to drain. As this unit does not have a water pump the dehumidifier must be placed higher than the drainage point.
3. Replace the water tank.