

# OPERATING THE DRYROBE® ADVANCE ZIP


The dryrobe® Advance features a chunky YKK® two-way reversible zip, which enables you to operate it with your arms either inside or outside of the change robe. You can also partially un-zip it from the bottom to allow more movement if needed for changing, walking, sitting or driving. There's also an easy to grab, branded pull tag too.

## How to operate when closing

- ① Pull the upper slider down until it touches the bottom slider.
- ② Insert the separable pin to the very bottom slider. Make sure it's completely inserted.
- ③ Pull up the upper slider to close the zip.

## How to operate when opening

- ① Completely pull down the top slider until it touches the bottom slider.
- ② Gently pull out the separable pin.



 **dryrobe®**