


**harmonix**

Awakening Sound and Speech



**EN**

# TravelerAI+ Series



## LCD Charging Case Product Manual


T110-BLK

T111-WHI

Version: IFU-T11X-LCD-EN  
August 2025

**harmonix**

Awakening Sound and Speech



harmonix.is  
harmonixhearing.com

# LCD Charging Compartment operation



## Lighting up the display screen

**Method 1:** Open the charging compartment cover the display will automatically light up.

**Method 2:** When the screen is off, click on the display screen to turn it.

**Method 3:** Press the multifunction button located under the charging case once to light up the screen.

## Turn off display screen

**Automatic shutdown:** After turning on the screen for 30 seconds without operation. the display screen will automatically turn off.

**Manual closing:** Press the Charging Case multifunctional button once to turn off the display screen.

**Note: First time use, please activate power**

Method 1.Charge and activate the charging case through the TYPE-C interface.

Method 2.Long press the multifunctional button on the charging case for 5 seconds to turn on the device

Tip: This product defaults to shutdown mode when it leaves the factory, First use requires activation and setup.

## Lock Screen Interface

Unlock: Slide to the right to unlock the screen



## Music Interface



⏮      ▶/⏸      ⏭  
Last Song      Play / Pause      Next Song

## Volume Adjustment Interface



⏪      ⏩  
Reduce Volume, minimum volume is 0      Increase Volume, maximum volume is 16

## Space Sound Interface



🎵      🎬      🎮  
Music Mode      Movie Mode      Game Mode

## Equalizer Interface



Switch between different EQ sound effects:  
Normal, Rock, Pop, Classic, Jazz

## Timer Alarm Interface



Switching requires setting the countdown alarm time: 5 minutes, 10 minutes, 30 minutes, 60 minutes

## Light Level Interface



Click the left button to decrease the screen brightness. Click the button on the right to increase the screen brightness.

## Language switch interface



Click to switch languages


## Find My Earphone interface



Click the L/R button, and the 1 will appear



Click to cancel and exit this function  
Click to start, the number 2 will appear and the headphone speaker will start emitting the sound



Click the stop button to stop the alert

## Tiktok Page flipping function

Needs to be connected to a wireless handset device such as a cell phone.

1. This function is only available for use with TIKTOK software, and other software many not function with it.
2. This feature may have compatibility issues with some phones, and some phones may not be able to use it.
3. If there are situations where it cannot be used, please ignore this feature



Click on this icon, the current short video will be liked



Clicking on this icon will switch to the previous short video

Clicking on this icon will switch to the next short video

## Flashlight interface



Click the button to turn on the flashlight, the entire screen turns white and brightness of the screen increases.

## Photography Function

Needs to be connected to a wireless handset device such as a cell phone

1. This function is only available for taking photos with the built-in camera of the phone. Other shooting software may not be able to use it.
2. This feature may have compatibility issues, and some phones may not be able to use it.
3. If there are situations where it cannot be used, please ignore this feature.



Open the phone camera, click the button, and the phone will start taking photos.

Note: when not in shooting mode, clicking this photo button will increase the volume.

## Definition of multifunctional buttons function.



Multifunction key

Click once: On/Off screen

Long press for 3 seconds: In power on mode, long press for 3 seconds, and the screen will pop up shutdown and restart icons.

Clicking on the icon can achieve shutdown or restart.

Long press for 8 seconds: In shutdown mode, long press for 8 seconds to turn on the device.

Long press for 10 seconds: Restart the system (display will show startup screen)

This operation can be performed when the system crashes and cannot be operated.

harmonix.is  
harmonixhearing.com

## Harmonix Customer Service Link



**Harmonix ehf.**  
Reykjavíkurvegur 64,  
220 Hafnafjörður  
Iceland

**Harmonix Technologies LLC**  
200 Crandon Blvd.,  
Key Biscayne,  
FL 33149,  
USA