

933002

MERRY
Christmas



2 Section Fibre Optic
Christmas Tree Owners Manual

Components

1 Top Section



1 Bottom Section



1 Connection Cable



1 Transformer



Depending on the tree model your tree will come with a variation of one of the stands below

1 Stand



3 Base Screw



OR

4 Legs



1 Stand Centre



Before Starting

Remove all caps from pole ends





1. Ensure all pieces are present
2. Ensure area of construction is flat, stable and free from children, pets and other obstructions
3. Ensure tree is away from sparks, flames or heat sources.

Estimated construction time:


1 Elf Assembly
Approx. 30 - 40 mins

1




Assembly


Assembling The Stand



Plastic Stand



Metal Stand



Branch Fluffing

1

Reach in to the centre of the lowest set of branches and gently push branches down flat.



2

Reach in to the centre of the pole underneath the branches you have just pushed flat and gently angle slightly upwards



3


3

Continue with steps one and two for the rest of the tree section.



Styling the Branch Tips

These types of branches should not be spread in varying directions.



Arrange the branches in a straight line angles slightly upwards to hide the trunk of the tree.

Tips & Maintenance

My tree doesn't look like it does on your website!



It just needs a fluff!

For our in depth fluffing and styling guide visit <https://www.christmastreeworld.co.uk/branch-fluffing>

My tree is wonky or has a lean!



The stand screws are not tightened evenly!

Working with another person. One person should grasp the shaft of the tree around halfway up. The second person should then loosen all the stand screws until the tree wobbles in the stand. Have the first person manoeuvre the tree until it is straight and hold it in position.

The second person will now tighten each screw.

Try turning each screw a half turn and working in a circle, until all are secure and the tree is held tight.

A few additional decorating and styling tips from our team



Our wooden tree skirts neaten up your tree's silhouette and tuck away unsightly wires

<https://www.christmastreeworld.co.uk/accessories/tree-skirts.html>

Finish The Room

Get the full festive effect by adding one of our pre-lit wreath and garland combinations.



<https://www.christmastreeworld.co.uk/christmas-decorations/wreaths>



Storage Solutions

Get your hands on one of our decoration storage boxes. They're perfect for keeping everything together and are sturdy enough to serve as an occasional seat!



Warnings!

Before each use, inspect your tree!






Take time to carefully ensure all parts of your tree are free from damage. Damaged parts may affect the structural integrity of your tree and can increase the risk of accidents, injury and damage to property.

If you find any parts of your tree are damaged or compromised, get in touch with our customer service team to see what we can do for you!

Do not position your tree near heat sources or open flames

While all our trees are manufactured with fire retardant materials, intense heat or open flames can still cause damage to your tree, lights, cables and home!



This is an indoor tree!

This tree is not suitable for outdoor use. Damp and wet conditions will cause the frame to rust!

Warnings!


Ensure tree is placed on a flat & stable surface

Not doing so will compromise the tree's stability and may result in damage to the tree, property or life. Make sure your tree is out of the way to avoid it being knocked or becoming a tripping hazard. Do not attempt to move tree once it is secured in the stand, doing so may cause tipping or damage to the tree.

Sloping floors,
ramps or stairs



Uneven surfaces or
raised platforms



Flat solid floor



Keep out of reach of children & pets

Enjoy your tree as a family, but keep little hands and paws away! Young children and pets should always be supervised around your tree to avoid damage and potential injury risks.



Further Use & Care Considerations

- Before each use, inspect any electrical components.
- Discard any electrical products which have cut, damaged or frayed wire insulation or cords, loose connections or exposed copper wire.
- Always unplug any electrical products when cleaning.
- Always unplug any electrical products when moving or re-positioning.
- Do not operate electrical products whilst they are in their packaging.
- Ensure care is taken when assembling pre-lit trees to ensure that wires are not snagged or cut.
- Do not connect any light chains or other electrical items that are not provided with this item to the light chain.
- Disconnect any electrical products from mains supply when not in use.
Transformer/plugs are sealed units and must not be tampered with.
- Replacement transformers are available, LED lights contain non-replaceable bulbs.
Please keep a free flow of air around any transformer/plugs when connected to mains supply.

The Environment

Here at Christmas Tree World, our goal is to become carbon neutral. We are prioritising electric vehicles and fully power our flagship offices with solar power. During our ecological partnership with the Borneo Nature Foundation, we have donated tens of thousands of pounds each year to help fund their reforestation efforts in the Borneo rainforest. At no extra cost to our customers, we have now funded the planting of over 100,000 trees!

Artificial Christmas trees are not a single use plastic, they are designed to be used year after year and with our 10 year foliage guarantee, you can be assured that your tree will last. If you no longer want or require your tree, please consider donating your tree to a charity shop, giving to a friend or even re-using parts of the tree to make new Christmas decorations that you can use for years to come before considering disposing of it. All packaging used is widely recyclable.

Please retain these instructions for future reference.

This document contains instructions for items with the following product numbers.

TR-FIO-CEL-MC-150	TR-FIO-AND-150	TR-FIO-BEL-180	TR-FIO-FRP-150	TR-FIO-SFP-150
TR-FIO-CEL-MC-180	TR-FIO-AND-180	TR-FIO-BEL-210	TR-FIO-FRP-180	TR-FIO-SFP-180
TR-FIO-CEL-MC-210	TR-FIO-AND-210	TR-FIO-BEL-240	TR-FIO-FRP-210	TR-FIO-SFP-210
TR-FIO-CEL-WW-150	TR-FIO-AND-240	TR-FIO-BEL-150	TR-FIO-MCA-150	TR-FIO-SFP-240
TR-FIO-CEL-WW-180	TR-FIO-RBLU-150	TR-FIO-BEL-180	TR-FIO-MCA-180	TR-FIO-SPS-150
TR-FIO-CEL-WW-210	TR-FIO-RBLU-180	TR-FIO-BEL-210	TR-FIO-MCA-210	TR-FIO-SPS-180
TR-FIO-GPON-WW-150	TR-FIO-RBCB-150	TR-FIO-BEL-240	TR-FIO-MCA-240	TR-FIO-SPS-210
TR-FIO-GPON-WW-180	TR-FIO-RBCB-180			TR-FIO-VES-150
TR-FIO-GPON-WW-210	TR-FIO-BEL-150			TR-FIO-VES-180



TR-FIO-VES-210
TR-FIO-VES-240
TR-FIO-WBR-150
TR-FIO-WBR-180
TR-FIO-WBR-210

Contact Us Today

The fastest way to contact us is to go to www.christmastreeworld.co.uk and click on the blue and white "Live Chat" icon.

You can also reach us via email on:
aftercare@christmastreeworld.co.uk

Alternatively, reach us by telephone
Monday to Friday on 01257 754 795

Christmas Tree World LTD
Unit 3, Enfield Industrial Estate
Enfield Street
Pemberton
Wigan
WN5 8DB

Made in China