

BlueAnt

ZONE X




**PREMIUM ACTIVE NOISE
CANCELLING HEADPHONES**

User Manual




WHAT'S IN THE BOX




Zone X Headphones




Carry Case




User Manual



3.5mm AUX Cable




USB Type-C Cable



Airplane Adapter

GET TO KNOW YOUR ZONE X | CONTROLS




POWER ON/OFF

Power ON:

Press and **HOLD** the Power button until the Status Indicator light turns **BLUE**.

Power OFF:

Press and **HOLD** the Power button until the Status Indicator light turns **OFF**.



NOTE: If not connected to a Bluetooth enabled device for 5 minutes, or the AUX cable is unplugged, the Zone X will automatically power off .



BLUETOOTH PAIRING

Power on the device and follow the steps below, to pair the Zone X with your Bluetooth enabled device.

1. Press and **HOLD** the Bluetooth button until Status Indicator flashes red and blue. The voice prompt, '**Bluetooth pairing**' will be heard.

To exit Bluetooth pairing mode, press and quickly release the Bluetooth button.

2. Open your device's Bluetooth menu.
3. Find and select '**BlueAnt Zone X**' to pair.



Bluetooth Menu
on your device



Zone X

4. Once paired, the voice prompt '**Connected**' will be heard, and the Status Indicator will flash **BLUE** every 5 seconds.

ACTIVE NOISE CANCELLING (ANC) MODES

The ANC modes offer 3 different listening experiences. Press the ANC button to cycle through the different modes below.

1. Noise Cancelling (NC) Mode:

● Green LED

This mode isolates your listening experience specifically to sound coming through the headphones and helps to block unwanted outside noise.

NC Mode is automatically activated by default, when the headphones are powered on. When NC Mode is active, the Status Indicator turns solid green.

2. Advanced Transparency Mode:

○ White LED

Advanced Transparency allows you to listen to the sounds around you, through the built-in microphones even while using the headphones.

To enter Advanced Transparency, press the **ANC** button once, and the voice prompt '**Transparency**' is heard. The **Status Indicator** will turn solid **WHITE**.


Note: Advanced Transparency allows you to hear background noise clearer, such as important announcements and street traffic. However, certain sounds may not be heard well, depending on the environment. Be cautious in places where an inability to hear ambient sound would be dangerous.

3. Advanced Transparency and NC OFF

⊗ LED OFF


Press the **ANC** button once more and the voice prompt, '**Transparency and Noise Cancelling Off**' is heard. The Status Indicator will turn off.

To turn **NC Mode** back on, press the **ANC** button again.



INSTANT AWARENESS MODE

Place the palm of your hands over the right earcup. The music is muted until you release your palm from the earcup.




TOUCH CONTROL (TOUCHPAD OPERATION)

The headphones include a multifunction touchpad, located over the right earcup. Use the following gestures to control audio playback and answer calls.


Manual Volume Control

To manually increase or decrease the volume, place your finger at either the top or bottom of the earcup as shown. Then slowly swipe up or down as shown below.

Slowly swipe down from
the top edge to the bottom




Slowly swipe up from
the bottom edge to the top




PLAY MUSIC

▶▶ Play/Pause:


Double tap the centre of the touchpad quickly to play or pause music



◀◀ Previous Track: Slide towards back



▶▶ Next Track: Slide towards front



CALL CONTROL



Answer an Incoming Call:

Double tap quickly to answer the call.

End an ongoing call:

Double tap quickly to end an ongoing call.





Rejecting a Call:

Touch and Hold during an incoming call to reject a call.


Voice Assistant:

Touch and **HOLD** until the default voice assistant of your device is activated. You can touch and **HOLD** again to cancel. (Depending on your phone, this may be Siri or Google).



DISCONNECTING

To disconnect from a device, press and **HOLD** the Bluetooth Pairing Button, until the Status Indicator flashes **RED** and **BLUE**. The voice prompt, '**Bluetooth pairing**' will be heard. You can now pair the headphones to another device.




Note: This feature is handy to quickly pair the headphones to another Bluetooth enabled device.

CHARGING

Insert the **USB Type-C cable** into the **USB port** of the headphones as shown below, and connect the other end to a USB Charger or charging device. The Charge Indicator will turn solid **RED** while charging and become solid **GREEN** when fully charged.

While charging, the headphones cannot be powered on or used.




Note: When the battery is low, the Status Indicator flashes RED twice every 5 seconds. The '**Battery very low**' voice prompt will be heard.

USING THE AUDIO CABLE

When connecting the 3.5mm AUX cable to the Zone X, the volume and tracks must be controlled from the source device. When you unplug the AUX cable and are not connected via Bluetooth, the headphones will power down.


If you want to use Noise Cancelling or Transparency without Bluetooth, please ensure the AUX cable is plugged in.



LED INDICATORS

The headphones include 2 indicators - the **Status** and **Charge** Indicators.

Both LED indicators are explained below



Status Indicator

Bluetooth

Pairing Mode	Flashes RED and BLUE
Connected	Slowly flashes BLUE (every 5 seconds)
Not Connected	Quickly flashes BLUE (every second)

ANC

Noise Cancelling	Solid GREEN
Transparency	Solid WHITE
Transparency and Noise Cancelling Off	Off

Battery

Low battery	Flashes RED once every 5 seconds
-------------	----------------------------------

Charge Indicator

Charging

Charging	Solid RED
Fully Charged	Solid GREEN

SAFETY INFORMATION AND WARRANTY TERMS

Important Safety Information

**PLEASE READ THIS ENTIRE DOCUMENT CAREFULLY, BECAUSE IT
CONTAINS IMPORTANT INFORMATION ABOUT THE USE OF
BLUEANT DEVICES**

WARNING - PROTECT YOUR HEARING

BLUEANT DEVICES CAN REACH VOLUMES
ABOVE 100 DECIBELS

ONLY CHARGE WHEN DEVICE IS CLEAN AND DRY

Care and Handling

Your BlueAnt Bluetooth device is a precision engineered instrument. To ensure its ongoing performance, you should look after it as you would any quality consumer electronic product, and use it in accordance with the instructions. BlueAnt recommends that you take the following precautions. Avoid leaving your device in direct sunlight.

- Do not leave your device, or use your device, in any area where the temperature may exceed 50 degrees Centigrade, such as inside a closed car on a hot day. Remember that on a hot day, the temperature inside a closed car may be significantly higher than the outside air temperature.
- Do not leave your device, or use your device, in any area where the temperature is likely to drop below 0 degrees Centigrade (32 degrees Fahrenheit).
- Do not leave your device, or use your device, in any area exposed to humidity, dust, soot, other foreign objects, smoke, or steam as this may cause your device to malfunction.

**PROLONGED USE AT HIGH VOLUMES MAY AFFECT
YOUR HEARING CAPACITY AND MAY RESULT IN
NOISE INDUCED HEARING LOSS (NIHL). TURN OFF
THE POWER TO YOUR DEVICE WHEN NOT IN USE.**

- Do not use any household or industrial grade detergents or cleaners to clean your device. If your device becomes dirty or smeared, in most instances a wipe with a dry or slightly damp cloth should be sufficient to clean it.
- Do not leave your Bluetooth device plugged into a wall for long periods after it is fully charged. BlueAnt does not recommend long periods of continued charging.
- Before charging your BlueAnt device, make sure that the AC outlet, adaptor and cable are not damaged. If you notice any abnormalities, seek advice from a qualified professional.

- If travelling internationally, ensure that your BlueAnt wall or car power adapter is approved for use in the country where you plan to use it and that the adapter voltage is suited to the local power supply.
- Should a fault develop with your BlueAnt product, contact BlueAnt for advice on how to proceed. Do not attempt to repair or alter any BlueAnt product yourself.

Approved Accessories

The use of accessories not approved by BlueAnt, including but not limited to batteries, antennas, wall adapters, car charger, ear gels and foam tips and convertible covers, may cause your BlueAnt device to malfunction or in the case of non approved electrical accessories may cause the device to exceed RF energy exposure guidelines.

Electromagnetic Interference

Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, electromagnetic configured for electromagnetic compatibility. Similar to a mobile phone, your BlueAnt device is a low power transmitter/receiver and is covered by regulations pertaining to such devices. Turn off your BlueAnt device in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

- When instructed to do so, turn off your BlueAnt device when on board an aircraft. Any use of a mobile device must be in accordance with applicable laws, regulations and airline crew instructions.
- If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your doctor or physician may be able to assist you in obtaining this information.
- If you are in doubt about whether your BlueAnt device can be safely turned on or used, please consult an authorised person in the location you want to use your BlueAnt device. If no authorised person is available or you remain uncertain, BlueAnt recommends that you turn off your Bluetooth device and any mobile phones unless they are required in an emergency situation.

Recycling Bluetooth Accessories

Do not dispose of Bluetooth accessories, such as chargers, speakers, headphones or headsets with your household waste. In some countries or regions, collection systems are set up to handle electrical and electronic waste items, and may prohibit or restrict how such items are disposed of. Check the laws and regulations for your areas to determine how to properly dispose of such items.

BlueAnt Limited Global Warranty

This product is covered by BlueAnt's limited global warranty for one (1) year from the date of purchase by the first consumer purchaser of the product. Please refer to warranty.blueantwireless.com for full terms and conditions.

THANK YOU FOR CHOOSING A BLUEANT PRODUCT

For warranty and technical support, please email care@blueantwireless.com website www.blueantwireless.com or call 1300 669 049

Register your BlueAnt product for warranty and new product updates at register.blueantwireless.com

BlueAnt

100% AUSTRALIAN
DESIGNED & OWNED

HELP & SUPPORT

Visit support.blueantwireless.com

Email: care@blueantwireless.com

Call: 1300 669 049

Register your BlueAnt product for warranty and new product updates at: register.blueantwireless.com



www.blueantwireless.com