

CHARGING




CONNECT

the charging pins.



CONTROLS



BUTTON FUNCTIONS

Left Sportsbud





Double click





Volume Down



Press & hold

the left MFB to decrease volume when music is playing or on a call

Right Sportsbud





Double click





Volume Up Press & hold

the right MFB to

increase volume when music is playing or on a call

Either Sportsbud











Answer Call 6



Click either MFB to answer a call





Double click either MFB to end a call



Reject Call



Press & hold either MFB to reject a call




Click either



MFB 3 x times to playing to activate/ cancel Siri/Google

BUDS LOST CONNECTION?



3. Remove sportsbuds from case

4. Place sportsbuds within 10cm from each other

Wait 10s until one sportsbud flashes white, then pair to phone

PRODUCT REGISTER

Scan me, to register & extend your Pump Air X3 warranty from 1 to 2 years



ONLINE MANUAL

Scan me, to view the full manual



ONLINE FAQ

Scan me, to view the FAQ



Visit warranty.blueantwireless.com for full terms & conditions

blueantwireless.com

Visit support.blueantwireless.com or email: care@blueantwireless.com