
takes 2 hrs

CHARGING




CONNECT

the charging pins.



CONTROLS



BUTTON FUNCTIONS

Left Sportsbud





Double click





Volume Down



Press & hold the left MFB to

decrease volume when music is playing or on a call

Right Sportsbud



Music Music

Double click



the right MFB to skip forward a track



Volume Up Press & hold



the right MFB to

increase volume when music is playing or on a call

Either Sportsbud





Music



Click either MFB to play/pause music





Click either MFB to answer a call





Double click either MFB to



end a call Reject Call



Press & hold either MFB to








MFB 3 x times to playing to activate/ cancel Siri/Google

BUDS LOST CONNECTION?



3. Remove sportsbuds from case

4. Place sportsbuds within 10cm from each other

Wait 10s until one sportsbud flashes white, then pair to phone

PRODUCT REGISTER

Scan me, to register & extend your Pump Air X3 warranty from 1 to 2 years



ONLINE MANUAL

Scan me, to view the full manual



ONLINE FAQ

Scan me, to view the FAQ



Visit warranty.blueantwireless.com for full terms & conditions

blueantwireless.com

Visit support.blueantwireless.com or email: care@blueantwireless.com