

# ergotune joobie footpad

assembly  
guide

## Assembly Parts

1. Assembled joobie x 1

2. joobie footpad  
(with pre-installed footpad screw)  
x 1

3. joobie footpad  
screw  
(pre-installed) x 1

4. Allen key x 1



### Assembly Video



Scan the QR Code to access our  
step-by-step assembly video.

### User Guide:




Scan the QR Code to  
access our user guides.




**Failure to follow these instructions  
may result in serious injury.**

1. This chair is designed to seat one person at any one time. Do not stand on this product or use it as a step ladder.
2. Do not use this product unless all bolts and parts are firmly tightened.
3. Check regularly that all bolts and fastenings are properly tightened and retighten when necessary.
4. Do not use if any parts are missing, damaged or worn.
5. Do not sit on the armrests.
6. Adult supervision is advised when used for children under the age of 10.


- 1** Locate the opening slot for your footpad on the front of your **joobie ergonomic chair (1)**.




- 2** Lean into the backrest to the lowest angle and lock it in place. Seat pan should be slid all the way in. This will provide space for **Step 3 & 4**.



- 3** Locate and unscrew the **preinstalled screw (3)** on your **footpad (2)** before sliding it through the slot in accordance to the diagram below.



- 4** Locate the screw hole on the footpad from the back of the chair and use the **allen key (4)** provided to secure the **footpad screw (3)**.



- 5** You are done with the assembly! The following diagram will show you how to operate the **joobie footpad (2)**.

