



Qi Wand System Care & Maintenance Guide

Proper care and maintenance of your Qi Wand System to ensure hygiene and long-lasting performance for personal or professional use.

Cleaning the Qi Wands & Gem Heads

- Always ensure the device is powered off and battery removed before cleaning.
- To preserve the beauty and integrity of the gemstones, we recommend cleaning them gently with a soft, dry cloth only.
- Use a soft, lint-free cloth slightly dampened with 70% isopropyl alcohol to gently wipe the rest of the wand's surface.
- Do not immerse the device in water or use abrasive cleaners.
- Avoid letting moisture enter the battery compartment or internal components.
- Ensure all parts are completely dry before the next use.

Storage

- Store your Qi Wand System in a cool, dry place away from direct sunlight.
- Keep them in the provided protective case when not in use to avoid dust and accidental damage.
- Remove batteries if the device will not be used for an extended period.

Maintenance Tips

- Inspect your devices regularly for any loose parts or irregularities.
- Replace batteries promptly to avoid leakage and ensure optimal performance.
- Do not attempt to disassemble the device, as it may void the warranty.

For additional support or professional guidance, please contact our Qi Life Support Team.