Grinde


USER MANUAL

WELCOME

Safety Precautions

- Keep the grinder out of reach of children. The grinder has sharp grinding blades that can be dangerous if not used properly. Children should not be allowed to handle the grinder or be in close proximity to it.
- Do not use the grinder if the power cord or plug is damaged. If the cord is damaged, do not attempt to repair it yourself. Contact a qualified technician for repair. Using a damaged grinder can be hazardous and cause electric shocks or fires.
- Do not immerse the grinder in water or any other liquids. Doing so may damage the motor and other components of the grinder, and also create the risk of electric shock. If you need to clean the grinder, use a dry cloth to wipe it down.
- Always turn off the grinder after use. Leaving the grinder on may cause the battery to drain and reduce the lifespan of the battery. It can also increase the risk of accidents if the grinder is left unattended.
- Do not use the grinder near flammable materials.
 The grinder generates heat during use, and this can be dangerous if it comes into contact with flammable materials. Keep the grinder away from flammable liquids, gases, or other substances that can ignite easily.
- Do not use the grinder if it is damaged or malfunctioning. If you notice any unusual noise, vibrations, or other signs of malfunction, stop using the grinder immediately and contact the manufacturer or a qualified technician for assistance. Continuing to use a damaged or malfunctioning grinder can cause injury or damage to the product.

PRODUCT OVERVIEW



IN THE BOX





USB-A to C



Cleaning Brush



Pre Rolled Cones Loader




Quick Start Guide




User Manual

HOW TO USE

Before use, please ensure the product is charged and unplugged




1. Open the Grinder: Turn clockwise to separate body and grinding area.




2. Adding Materials: Place the material evenly on the bottom grinding tray (Be careful not to overfill; you can always grind twice if you want more material).



3. Close the Grinder: Twist counterclockwise to tighten the body and grinding area until you hear a clicking sound.



4. Lock the Grinder: Push up the lock button to engage the lock. Then you will see a "lock" icon.



5. Start Grinding:
To start the grinding process, simply press any button.
Press the other side of the button to grind reversely.



6. Here We Go: Finally, your material will be in the peak of its grinding game, ready to rock and roll!

OTHER FEATURES



1. Patented Sword-Shaped Disc

We have ingeniously crafted the grinding teeth in a sleek "sword" shape, striking the perfect balance between "cutting" and "grinding". This exquisite design not only maximizes grinding efficiency but also enhances the release of delightful flavors locked within the material.



2. Anti-static Funnel

Static electricity can cause grinding particles to adhere to plastic surfaces, creating a nuisance during the process. However, our innovative funnel is equipped with anti-static materials precisely designed to combat this issue. By incorporating these materials, we minimize the undesirable adhesion of ground particles to the inner walls of the funnel. This ensures a more efficient and hassle-free grinding experience.

OTHER FEATURES



3. Odor-proof Cup

The odor-proof cup features scale markings for convenient measurement of ground material



4. Double-Locking Mechanism

K1 herb grinder features a double-locking mechanism that ensures stability and peace of mind.

With our innovative locking system, you can say goodbye to any worries about accidents or mishaps while grinding your herbs. Unlock the secrets of perfectly ground herbs with our reliable and secure grinder. Its dual-locking feature keeps everything in place, allowing you to focus on the flavors and aromas you love.

OTHER FEATURES



5. Indicator Light:

The grinder is equipped with an indicator light on the side to display its charging status. Here are the indications provided by the light:

- a. Slow flashing: The indicator light flashes slowly when the grinder is being charged, indicating an ongoing charging process.
- b. Steady or off: When the battery reaches over 90% charge, the indicator light becomes steady. It turns off completely when the grinder is fully charged, indicating that it is ready for use.
- c. On during operation: The indicator light remains on while the rotation button is pressed, indicating that the grinder is in use and the motor is running. The light turns off when the grinder is not in use.
- d. Fast flashing: When the power level drops below 20%, pressing the button will cause the indicator light to flash rapidly, providing a visual reminder to recharge the grinder.

BATTERY CHARGING

- The grinder features a built-in battery, eliminating the need for a plug during operation. You can conveniently charge the battery using the provided charging cable.
- When the battery is low, simply connect the charging cable to the side charging port of the grinder. The indicator light will slowly flash, indicating that the battery is being charged.
- It takes approximately 30 minutes for the battery to reach a full charge.
- When the battery exceeds 90% charge, the indicator light becomes steady. It will turn off once the battery is fully charged, indicating it is ready for use.

MAINTE-NANCE

- Always unplug the grinder before cleaning it. This will help to ensure your safety while cleaning the product.
- Clean the grinding disc and grinding heads with a dry cloth. Use a dry brush to wipe off any residue or debris on the grinding disc and grinding heads. Do not use any water or other liquids to clean the grinder.
- Do not use any abrasive materials or cleaners to clean the grinder. This may damage the grinding disc and grinding heads, and affect the performance of the grinder.

MORE INFORMATION ON OUR WEBSITE!

We've put our heart and soul into creating this product to make your experience with the electric grinder a breeze. If you ever find yourself in a pickle or need a helping hand, don't hesitate to reach out to us. We're here to save the day, one grind at a time! Thank you for choosing our awesome product, and happy grinding!

Model: K1

Input: 5V-190mA

Battery Capacity: 500mAh

Rated Voltage: 3.7V

Operating Temperature: 0°C∼55°C

E-mail: support@kactuskutter.com

Website: kactuskutter.com

Address: RM A07, 1701-02 New Trend

Centre, 704 Prince Edward Road East, SAN PO KONG KLN

HONG KONG