


CONTROLLER QUICK GUIDE


FR

ZEHUS


1 Chargez la télécommande avant usage.




2 Allumez la télécommande avec le bouton central.




3 Connectez votre télécommande avec l'App Zehus, dans le menu du véhicule "Ajouter un appareil", puis suivez les étapes.




4 Fonctions de la télécommande



5 Etats des LEDs et indicateurs LED dynamiques



6 Montez la télécommande sur le guidon en utilisant le support dédié.



Notes de sécurité!

- Utilisez toujours votre roue avec la protection du connecteur.
- Toujours éteindre sa roue lors de maintenance, services.
- Protégez votre roue de chaleur sévère, feu et jet d'eau sous haute pression.
- N'ouvrez pas votre roue
- Chargez la batterie dans un environnement sec et propre.

Subject to change without notice.

The specifications on this document are subject to change at Zehus decision. Zehus assumes no responsibility for any claims or damages arising out of the use of this document, or from the use of modules based on this document, including but not limited to claims or damages based on infringement of patents, copyrights or other intellectual property rights.