

Thank you for purchasing an Enso Pearl!

- 1 Prepare
 Pull the plastic tab out from the back of the Enso Pearl to power it up.
- Press O
 Use + & to adjust the time.
- **3** Set the Alarm

Press 0

Use + & - to adjust the Alarm time.

Press To to toggle Alarm on or off.

QSG-EC-200-1.0



Basic Timer Operation

The Enso Pearl functions as an Interval or Repeat Timer.

Default T1 Interval (Int) Hr:Min
Timer T2 Interval (Int) Min:Sec

Settings T3 Repeat 🗂 Min:Sec

- 1 Press 📆 , 📆 , or 📆 to Set Timer.
 - 2 Press + & to Adjust the Time.
 - Press >> to Edit Next Interval.

 Repeat Mode: Pressing Increases # of Repetitions.
 - 4 Press START-STOP to Start Timer.

Timer O Press & Hold to Hide Numeric Display During Timer.