




TONE SELECTION / BLUETOOTH MODE

Press to switch between 12 sounds

Hold for 5 seconds to toggle between sounds and Bluetooth mode.



VOLUME
DOWN

+

VOLUME
UP



POWER

Press and hold for 1 second to turn the unit on/off.

Press and hold for 5 seconds to turn the nightlight on/off.

SOUNDS

- | | |
|------------------|----------------|
| 1 White Noise | 6 Ocean |
| 2 Brown Noise | 7 Rain |
| 3 Table Fan | 8 River |
| 4 Box Fan | 9 Summer Night |
| 5 Airplane Cabin | 10 Fireplace |

Ambient Tracks

- 11 Moonrise
- 12 Daydream

BOTTOM INDICATOR LIGHT

Light Off: Battery is above 20%

Blinking Red: Battery is below 20%

Steady Red: Battery is charging

Blinking White: Unit is in Bluetooth pairing mode.

LOOP LOCK

Loop the knot through the hole to hang your Go.

Squeeze the top and bottom to release the knot.



Sleep uninterrupted.
SNOOZ-Go-2 comes with a 1-year warranty.
Please scan the QR code to register.



Questions? We're here to help.

WEBSITE
getsnooz.com

EMAIL US
cs@getsnooz.com

INSTAGRAM
[@snooz](https://www.instagram.com/snooz)

Read Me

SNOOZ-Go-2 User Manual