


ASSEMBLY INSTRUCTION.

MODEL : CASA DINING CHAIR


CODE	PART	DESCRIPTION	QTY
A		M6 X 20MM JCBC SCREW (FOR FRONT LEG)	8 PCS
B		SPRING WASHER	12PCS
C		FLAT WASHER	4 PCS
D		M6 X 50MM JCBC SCREW	4 PCS
E		ALLEN KEY	1 PC

NOTE: PART LIST AND HARDWARE SHOWN IS PER/PC

1)



(i) BACK PANEL : 1PC



(ii) FRONT LEG



(iii) SEAT : 1PC



COMPLETED ASSEMBLY.

