

VELORETTI

ELECTRIC

Veloretti Electric Diamond display user manual



Turning display ON/OFF

The Diamond Display can be turned ON by pressing the MENU button for 4s. The display can be turned off by pressing the MENU button for approx. 4 seconds until message "BYE" appears on the central screen

Changing the menus

Changing the menus is carried out by pressing the MENU button. Display has the following menus: Speed, Assist level and SoC.

State of Charge Central display screen

Your battery level is showed as a circle bar on the edge of the screen (indicates % of the State of Charge (SoC))

Changing assist levels in Menu

Changing assist levels can be done by pressing the UP and DOWN arrow buttons. The chosen assist level is presented on the screen

Switching the lights

Switching the lights can be done by pressing the UP arrow for 1,5 seconds.

Settings

In order to access "Settings" menu it is necessary to hold down the MENU button for 1,5 seconds. Settings menu is indicated by display screen message "Settings". Under settings it is possible make the following adjustments:

- Change units (metric vs. imperial)
- Change the position of the display - LEFT or RIGHT side of the handlebar