# **OASIS/OASIS+ Assembly Manual**

#### Step 1:

Slide two steel panels into a corner post to create a L-shape.

Install hardware:

- Exterior: Screw
- Interior: Washer, Wingnut

## Step 2:

Install the second and third corner post on each end of the L-shape

### Step 3:

Slide the third steel panel into the corner post and install hardware

## Step 4:

Install the fourth corner post

## Step 5

Slide the fourth steel panel in between the third and fourth corner post





