

Smart Holder Guide

How to use the Smart Holder

The Smart Holder attaches under the two vertical straps on the backside of the Palissy product.

A small area about halfway up is left unstitched to slide the Smart Holder in.

You can remove the Smart Holder and store it for your next trip when not travelling.



CARL FRIEDRIK

