

Wheels Guide

How to attach wheels?

Open the lining of the suitcase with the puller. Arrow in the image below shows the location of the puller.



Unscrew the 4 screws shown below (located on top of the wheelbase).

- Hold the wheel from the outside for security
- Please do not discard of the screws as they will be needed when inserting the new wheels.



Align and insert the new wheels and screw the existing screws in place and re-zip the lining

CARL FRIEDRIK