

VSETT LCD Replacement

Updated 02/16/2022

Applicable Models: VSETT 8, VSETT 8+, VSETT 9, VSETT 9+, VSETT 10+, VSETT 11+

Repair Difficulty: 1/5

Required Tools / Materials:

- Set high quality Allen wrenches

1) Snip the zip tie (2) below.

2) Remove right hand grip by loosening (1) bolt below. Remove the end cap pieces.



- 3) Lower the right handlebar. This creates enough slack in the wiring to remove the hand grip without breaking the turn signal wires.
- 4) Slide the hand grip off. Be gentle with the turn signal wire. Raise the handlebar back up.



- 5) Loosen the brake lever clamp. Slide the brake lever off.
- 6) Loosen the the two bolts on the bottom of the LCD display. Unplug the old LCD display and slide it off the handlebar.
- 7) Slide the new LCD onto the handlebar and plug it in. Slide the brake lever back onto the handlebar.
- 8) Lower the handlebar down and reinstall the hand grip. Raise the handlebar back up and reinstall the end pieces into the hand grip.
- 9) Adjust the grip, brake lever and LCD to suit your tastes.

Let me know if you have any questions.

