

A woman with long brown hair, wearing a black sports bra and black bikini bottoms, is sitting on a wooden bench inside a sauna. She is looking out through the glass door of the sauna. The interior of the sauna is made of light-colored wood. The glass door has a black frame and a white handle. The background outside the sauna is dark.

coldture

Outdoor Sauna Light

Installation & Controller Guide

PREMIUM SAUNA LIGHTING



Made in Austria

Precision-engineered with European craftsmanship for long-lasting quality.



Heat-Proof Technology

Built to withstand extreme sauna temperatures up to 125°C (257°F) without compromising performance.



Powerful, High-Quality Light

Provides intense, clean, and consistent illumination that enhances the sauna experience.




Energy Efficient

Uses less power without sacrificing brightness - designed for lower energy consumption.



Flicker-Free Experience

Engineered for smooth, flicker-free lighting to create a relaxing and comfortable atmosphere.



Two Size Options

Available in batten-style LED bars in 46" and 72" lengths to suit any sauna layout.



Easy to Install

Includes mounting clamps for fast and secure installation.



Wireless Cedar Wall Controller

Beautifully designed cedar wall-mounted controller lets you control brightness and ambiance wirelessly.



6-Year Warranty

Peace of mind with a full 6-year manufacturer's warranty.

EACH SYSTEM INCLUDES:

- 1x LED Batten Light Bar
- 1x Standard Cable 3m
- 1x Power Supply
- 3x Mounting Clamps incl. Screws
- 1x Mounting Manual
- 1x Wireless Cedar Wall Remote




Confirm all components are present before installation.

WALL REMOTE – THE 4 BUTTON USAGE CONCEPT

- ➔ **Next Button**
Switches to the next colour and activates the single colour mode.
- ↻ **Automatic Button**
Switches to the next colour and activates the automatic mode.
- ☀ **Brighter Button**
Increases the light intensity or mixes pastel colours.
- 🌙 **Darker Button**
Decreases the light intensity. This button can also be used to switch the lamp off.



EASY INSTALLATION: ONLY ONE SCREW NEEDED



SYNCHRONIZING THE CONTROLLER WITH THE LIGHTS

To synchronize the controller with the lights:

1. Unplug the power supply (if it was plugged in).
2. Wait at least 20 seconds (so that the supply voltage has died down).
3. Plug the power supply back in.
4. Within 10 seconds of plugging it in, press the **Next** ➡ button on the remote control (press once briefly).
5. The LED at the light will flash green confirming the light was synchronized to the wall remote.
6. After a short period of time the flashing LED will turn into a permanently green light.

The light will now only accept commands of this wall remote control.

You can redo the synchronization process at any time by following the above steps.

