



| Handle | Camera Diameter | 6.2mm | 8.5mm |
|---------|---------------------|--|-----------------------|
| | Snake Tube Length | 5ft (1.55m) | 5ft (1.55m) |
| | Snake Tube Material | Flexible metal spring hoses | Flexible metal shaped |
| | FOV | 80° | 80° |
| | Depth of Field | 15~100mm | 15~100mm |
| | Camera Light Source | 6 Bright LED lights | 8 Bright LED Lights |
| | Sensor | 1/9" COMS | 1/5" COMS |
| | Rotation Angle | Maximum 210 ° | Maximum 210 ° |
| Monitor | Screen Size | 5 inch | |
| | LED Adjustment | Support | |
| | Power Supply | 3000mAh Polymer Lithium Battery | |
| | Work Time | About 6h | |
| | WIFI Connection | Support | |
| | Language | Support 8 Different Languages | |
| | Storage | Standard 32GB–TF Card (Aaximum Support 64G | |

Application Environment

For professional maintenance and inspection personnel, this portable, articulating endoscope can be used to inspect many locations invisible to the human eye without disassembly or damage. This is the perfect tool to perform precision inspection of engine, automobile, HVAC, plumbing, computers, buildings, electrical and more...

| Operating Environment | Snake tube | In The Air: -10°C to 50°C | |
|-----------------------|------------|--|--|
| oporating Environment | Machine | In The Air: -10°C to 50°C | |
| Input Voltage | | DC5V | |
| Humidi | | 10% to 90% | |
| Protection Class | | Do Not Operate in The Rain/Do Not Operate in The Liquids | |

NOTICE

- Please read this manual carefully before using this product, and follow the instructions to avoid the damage caused by improper use.
- Disassembly of this product is forbidden, and the compay is not responsible for any loss caused unauthorized disassembly of this product.
- Do not rub the product against hard objects to avoid scratches, abrasion, or other hardware by damage.
- Please note that the exposed metal parts of this product are conductive, please avoid exposure to live electrical circuits.
- Keep this product out of the reach of children.
- This is not a medical product, it is NOT intended to be used in any animal body.
- Keep the product clean and avoid direct exposure to oil or corrosive liquids.
- This product is not waterproof, please avoid contact with liquids.
- Make sure the dial returns to the neutral position before pulling out the coiled tubing. Do not turn the dial violently.
- Do not twist or pull the articulating probe at the front of the coil.
- Please handle gently, do not bend the camera probe excessively, the bending limit of the tube is one circle.

- 4 -

