

hexon



user
guide

Table
of
Contents

1 Introduction

- About Hexon Desk

2 Usage Instructions

- Top Desk Ecosystem
- Side Desk Ecosystem
- Under Desk Ecosystem
- The Health Coach™

1 introduction






About Hexon Desk

The Hexon Desk is an innovative workspace solution designed to promote a Health Ecosystem by providing a clutter-free environment and enhancing productivity.


With features such as a wire cabin, quick access hatch, magnetic desk top edge, and modularity, the Hexon Desk offers a versatile and organized workspace.

Why You'll Love It



1. **Health Ecosystem and Modularity:**

Achieve a **clutter-free environment** for enhanced productivity with the Hexon Desk's Health Ecosystem. Benefit from **modularity and easy assembly**, ensuring a customizable workspace tailored to your needs.



2. **Convenient Access:**

Provides **easy access** to frequently used items and cables.

² usage instructions






Top of Desk

The Hexon Desk's top is designed for a clutter-free workspace. It features the Wire Cabin and Quick Access Hatch, hidden areas to keep cables out of sight for a tidy workspace.


These spaces provide easy access to cables or a multiplug, without disturbing items on the hatch. The Magnetic Desk Edge neatly stows frequently used cables with a stopper, further maintaining workspace cleanliness.

How to use



1. Wire Cabin & Quick Access Hatch:

Position the multiplug to the left or right of the quick access hatch for **convenient access to the static cables and plugs**. Ensure the multiplug is placed within reach to conveniently connect and disconnect devices without disturbing stationary items on the desk.



2. Magnetic Desk Edge

Position the cable stopper at the **designated parking lane** for **easy access to frequently used cables**.




Side of Desk

The standout feature of the hexon desk is its ability to create additional free space on the side, allowing you to maximize your desktop working area.


You'll love the convenience of threaded holes and quicksnap screw caps for attaching accessories without cluttering your desktop. This innovative design ensures a tidy and organized workspace, promoting efficiency and productivity.

How to use



1. Quicksnap Screw Caps:

Simply assemble the quicksnap screw cap by placing it on top of the flanged screws. The magnetic caps will securely hold the screws in place, serving as **convenient handles for tightening or loosening** them.



2. Attachment of Accessories:

Simplify attaching accessories by utilizing the **threaded holes** on the side of the desk. Secure them effortlessly with **quick snap screw caps** for a hassle-free setup.





Base of Desk

Experience the convenience of concealing larger items within the undermount accessories, ensuring they are easily accessible within arm's reach.

With the undermount accessories, you can efficiently manage your workspace, keeping essential equipment close at hand while maintaining a clean and streamlined appearance. Say goodbye to clutter and hello to enhanced efficiency with the dexon desk's practical and functional design.

How to use



Effortless assembly and relocation:

Enjoy **effortless assembly and relocation** with **magnetic accessories** on the hexon desk. Simply **align the accessories with the metal plate and secure them in place** using quicksnap screw caps for a hassle-free setup and adjustment process.




Health Coach™

We know, it's hard to stay active when you spend at least 8 hours a day at your desk. That's why you got the Health Coach™ Controller!


Discover the convenience and health benefits of the Health Coach™ Controller. With its height adjustable feature and sit/stand reminder, you can customize your desk height to create a comfortable and health-conscious work environment. This promotes better posture and overall well-being, enhancing productivity throughout your day.

How to use - Height Adjustments




Going Higher

Rotate clockwise to increase the height of your desk.



Going Lower

Rotate anti-clockwise to lower the height of your desk.






How to use - Basic Navigation

Locking & unlocking


How it works

Rotate either side 2 times to initiate an unlock. This function will only be activated when you rotate the same side twice.






Home Menu Navigation



Hold the home key  for 3 secs to bring up the menu page. Rotate the controller left and right OR tap **1** and **3** to toggle between menu functions.

Menu functions available

-  Function 1:
Reminder Interval
-  Function 2:
Desk Height Limit
-  Function 3:
Return to Main Display

How to use - Reminder Interval

Reminder interval

1

Hold the home key for 3 seconds

2

Tap the home key to select function 1

3

Rotate to toggle between intervals
15 mins | 25 mins | 35 mins | 45 mins
Tap home key to select desired interval

4

Successfully saved!

5

Tap any key OR rotate the controller to stop the vibration

Recommended Frequency for Sitting & Standing

It is not ideal for your health and posture when you stay in one position for too long, be it standing or sitting.

The key is to alternate between positions regularly.

Experts recommend standing at least 30mins a day to enjoy health benefits!

Tip: Start at 15 mins per hour, then gradually increase your stand time each week.

The ideal sit-to-stand ratio differs for individuals. Find what's comfortable for yourself.

How to On/Off reminder

1

Double Tap the home key to ON or OFF the reminder


2

Progress bar indicates that reminder is on
Tap any key to stop/restart the reminder

How to use - One Touch Adjustments


Save your most-used heights as one-touch presets


1




Adjust to desired height

2




Tap the home key  once

3



Tap on 1, 2 or 3 to save the height to that memory slot


4




Your preset is saved! Tap on 1, 2 or 3 to adjust the desk to its saved height with one touch


Quick Fix for Error

1




Rotate the controller anti-clockwise and hold it in place till the display changes to 

2



Rotate the controller anti-clockwise once more until the desk is at the lowest height

3



Rotate the controller anti-clockwise until the display is showing the height of the desk. Reset is complete.

Not used to standing at your desk?

Use these tricks to ease yourself into the habit:

- 1. Use Health Coach’s customisable timers to remind yourself when to change positions
- 2. Stand up during activities that don't require constant typing eg. on calls
- 3. Optimise your ergonomics
- 4. Get your friends and family involved

How to use - Safety Feature

Set desk height limits

1

2

3

100cm


Adjust to desired maximum/minimum height

2

2

3

<🔔>
1/3


Hold the home key  for 3 seconds

3

2

3

<↑↓>
2/3

Rotate to toggle to function 2, tap home key  to select

4

2

3

<↑MAX>

Choose if you wish to set the <MAX> or <MIN> desk height limit. Tap the home key  once to save the current desk height

5

2

3

✓

Successfully saved!

What do they mean?

<↑MAX>

Highest desk height limit



<↓MIN>

Lowest desk height limit



<↑↓OFF>

Switch off desk height limit



Work safely, avoid collision with objects in your surroundings



NEED ASSISTANCE?

Need help? Give us a call if you have any questions about EverDesk in general, or if you are struggling with your assembly!

