

QUICKPLAY

TEKKERS TRAINER



INSTRUCTIONS

SETTING UP




Follow the below instructions or scan this code for an easy to follow setup & takedown video:

STEP A:

Assemble the base frame by connecting the Side Poles (1) to the Center Bar (2):

NOTE: a slight upward bend in the center of the base bar is normal.



STEP B:

Slide the Upright Post (3) through the sleeve of the Ground Pass Net. Then insert the post into the base frame and lock with pin (4). Keeping the sleeve bunched at bottom, repeat on other side:



NOTE: Ensure the angled sections of the Upright Posts are pointing away as shown:

STEP C:

Insert the Fiberglass rods into the Upright Posts, then attached the frame straps (x5) and bungees (x2):



STEP D:

Attach the Loop Pass Net to the top and a bottom corners of the frame. NOTE: Ensure the logo is at the top of the net and frame straps (x4) are positioned at the bottom of the net:



STEP E: Attach the frame straps (x4) on both sides of the base frame:



STEP F: Secure with ground stakes (x4) on both sides, in the locations shown below:



STORAGE: Reverse STEP F through to STEP A and then store in the carry bag provided.

TEKKERS TRAINER



CARRY BAG



GROUND STAKES



SIDE POLES (x2)



GROUND PASS NET



CENTER BAR (x3 pre-connected)



UPRIGHT POSTS (x2)



LOOP PASS NET



FIBERGLASS (x2)

TEKKERS Trainer features a quick and easy set up, which can be completed in under 3 minutes. Follow the enclosed instructions or scan this code for a video guide to setup & takedown:



The TEKKERS Trainer is a portable product and has been designed to be set up and taken down quickly and easily.

It should not be left up after use. To ensure maximum product lifespan of your TEKKERS Trainer please ensure to pack it away and store the product in a dry place.

WARNINGS:

Please read this page carefully to get the best from your TEKKERS Trainer:

- 1. Must be assembled by an adult.
2. This product is not suitable for children under 5 years of age. Small parts and netting can cause choking / strangulation.
3. Only use on a flat surface.
4. Check the TEKKERS Trainer is fully and properly assembled before use.
5. Check the TEKKERS Trainer is secured to the ground before use.
6. Do not climb or hang on the TEKKERS Trainer.
7. Regularly check for wear and tear. Stop using if any part of it breaks. Failure to do so may result in injury.
8. Disassemble after use. If TEKKERS Trainer is wet / damp, allow to air-dry before placing in the carry bag for storage. Do not leave outdoors in adverse weather conditions.
9. Keep away from heat sources and do not leave in a hot vehicle.
10. Use under adult supervision. This product is not suitable for children under 5 years of age.
11. Not suitable for use in high winds.

PARTS WARRANTY:

This product must be disassembled after use and stored in a cool, dry place or the warranty is invalidated.

Register your warranty within 15 days of purchase visit: Warranty.QuickPlaySport.com or scan this code:



Table with 2 columns containing instructions and warnings in German, French, Spanish, and Polish.

Table with 2 columns containing instructions and warnings in Italian, Finnish, and Swedish.

THANK YOU! For choosing the QUICKPLAY TEKKERS Trainer. We hope you enjoy and get years of use out of this product.

If you have any issues, please do not return it to the store. Instead contact us directly:

info@quickplaysport.com

We promise to resolve it or your money back.

At Quick Play Sport we think sport is all about taking part. We develop innovative products that help athletes and coaches at all levels of sport, perform to the best of their ability.