









 POWER	<b>Turning On</b>	Plug the power cable into a socket and press the power button. You will hear a beep and the dehumidifier's control panel will turn on.
 MODE	<b>Selecting a mode</b>	Press the mode button to cycle through the available modes: Normal Mode  , Low Power Mode  , High Power Mode  , Laundry Mode  .
 FAN	<b>Fan Mode</b>	To turn off the dehumidifying function and just use the unit as a fan press the button.
 SET %	<b>Setting a target humidity</b>	When your dehumidifier is in Normal Mode  you can set your target humidity. Once this is reached the unit will switch off. Press the button to choose a humidity from 30-80%.
 TIMER	<b>Setting a Turn-On Timer</b>	When the dehumidifier is off (but still plugged in at the wall), tap the timer button until you reach the desired number of hours before you want it to turn on. The 'Hr' light will light up when a timer is set.
	<b>Setting a Turn-Off Timer</b>	When the appliance is on, tap the button until you reach the required hours before it turns off. The 'Hr' light will light up when a timer is set.

### EMPTYING THE WATER TANK

When the water tank is full the red indicator light will flash and the product will make a beeping sound. The dehumidifying function will automatically stop.



1. Press the  button to turn the dehumidifier off.
2. Gently pull the grooves either side of water tank and gently pull the tank out from the back of the dehumidifier.
3. Use the handle to empty the water tank.
4. Once empty, slot the tank back in carefully.

### SETTING UP CONTINUOUS DRAINAGE

For long term use it is recommended to connect a hose for continuous drainage.

1. Remove water tank.
2. Insert the hose into the water hose connector, ensuring it is connected properly.
3. Ensure the hose end has a suitable drainage outlet (e.g. a drain or bucket). Ensure that the hose and the Dehumidifier are placed at least 15cm above where the hose is depositing the water.
4. Slot the tank back in carefully.